

“SMART” WATER-BASED EPOXY COATINGS FOR CORROSION PROTECTION OF AA2024


Bruno Martins¹, Darya Snihirova¹, K. Szczepanowicz², P. Warszynski², M.
F. Montemor¹

1 - ICEMS - Instituto Superior Técnico, Technical University of Lisbon, Portugal

2 - Institute of Catalysis and Surface Chemistry, Polish Academy of Science, Krakow, Poland

Chromium (VI) Surface Treatment:

- Favours the adhesion of organic coatings
- Increases corrosion resistance
- Easy application
- Toxic
- Cancerigenous
- Pollutant
- High elimination cost



(USGS Annual Publications - Mineral Commodity Summaries)

Goal

- Develop more effective “smart” coatings for corrosion protection of AA2024




Impact

- Elimination of chromate pigments from current formulations used in the aircraft industry;
- Reduced thickness and decreased number of layers;
- Increased corrosion resistance, lifetime and mechanical properties, by addition of “smart” additives, conferring self-healing properties;
- Application to various industries (e.g. aeronautical, automotive, etc.).

Introduction


Healing Processes

Mechanical Trigger



1st - Barrier properties are damaged;


2nd - Corrosion onset;



3rd - Release of healing agents contained in the capsules;

4th - Recovery of the barrier properties

pH Activation




Inhibited area

Introduction

Healing Processes


pH Activation



Reservoir filled with
corrosion inhibitor

pH sensitive layer
senses $\uparrow \Delta \text{pH}$ on
the active surface


Pores open



Inhibiting layer
Corrosion stops

sensitive layer
detects pH
stabilization

Pores close





Introduction



Healing Processes

- Stimulus: Mechanical Action
- Response: Capsule rupture – healing by polymerisation

Without capsules




With capsules



Introduction

“Smart” Epoxy Coatings



TiO₂ nanocontainers loaded with 8-hydroxyquinoline (corrosion inhibitor).

SEM image


Progress in Organic Coatings, **2012**, 74, 418– 426

Confocal Microscope
(Under UV light)

Early and non-invasive corrosion detection.

Confocal Microscope

Progress in Organic Coatings, **2011**, 71, 406–412





“Smart” Additives

- Compatibility with the host matrix
- Compatible with coating thickness
- Identical/improved barrier properties
- High loading capacity
- Stimuli-responsive
- Long stability


Polyelectrolyte Nanocapsules

Polyelectrolyte (soft) shells - Layer by Layer



Zeta potential with number of layers

SEM Image






Size ~60nm
Zeta Potential +40mV

Tested coatings:

- Coating 1 – Epoxy Resin with 35% of water suspension of negatively charged capsules without inhibitor
 - Coating 2 – Epoxy Resin with 35% of water suspension of negatively charged capsules with inhibitor
-

Used Techniques:


- SEM  Coating Morphology
- EIS
- SVET   Electrochemical Techniques
- SIET

Morphology (SEM images)

Cross-Section

Top View

Thickness = $42\mu\text{m}$



Cross-Section


Top View

Blank


Cross-Section

Top View

$49\mu\text{m}$




$37\mu\text{m}$



Coating 1



Coating 2

Blank – Epoxy without Nanocapsules





EIS Measurements


Coating 1 –
Epoxy + Empty
Nanocapsules




Coating 2 –
Epoxy +
Nanocapsules
with MBT+LI




Fittings (Coating Layer)



Fittings (Oxide Layer)



Fittings (Substrate)



Defect (SVET & SIET)

Blank coating



Scan size: W0.9 x H0.96 mm

Difference in pH

1h \rightarrow 5.9 – 5,5

15h \rightarrow 6 – 5,3

Δ pH

Activity increases

Difference in I





1h \rightarrow -3 to 3

15h \rightarrow -6 to 6

Current
density

Activity increases

pH map



1h

15h

Current map $I = \mu\text{A}/\text{cm}^2$

Defect (SVET & SIET)

Coating + MBT filled nanocapsules




Scan size: W1.0 x H1.1 mm

Difference in pH

1h \rightarrow 6.1 – 4.9

15h \rightarrow 6.5 – 6.2

Δ pH



Activity decreases

Difference in I

1h \rightarrow -3 to 3




18h \rightarrow -6 to 6

Current
density




Activity vanishes

pH map



2h



18h

Current map $I = \mu\text{A}/\text{cm}^2$

Mechanism of self-healing

Defects open a path for Chloride ions




The corrosion process starts on the damaged oxide



The inhibitors is released because nanocapsules are broken and because their shell is pH sensitive



Inhibition of the corrosion process



Conclusions

- Allows the use of water as solvent (Green).
- Nanocapsules were successfully prepared and characterised.
- There is a very good compatibility between the nanocapsules and the epoxy based matrix.
- The capsules do not affect greatly the morphology of the coating.
- The coatings embeded with nanocapsules, displayed the best performance.
- A recovery of the low frequency impedance was observed in damaged coatings.
- Localised electrochemical techniques revealed self-healing of the corrosion activity.

Acknowledgements

- MUST project and partners that supplied materials for coatings (EADS and Mankiewicz)
- FLAD
- C3P

**Thank You For Your
Attention!**